


KENSINGTON ALTERNATIVE WOOD BLINDS

MEASURING GUIDELINES

Accurate measurements are essential, for both correct pricing and proper fit. Use only a hard-edged ruler or steel tape, never a cloth tape. For inside mounts, width measurements should be rounded down to the nearest $\frac{1}{8}$ " to prevent blind from binding against the window casing.


INSIDE MOUNTING (IB)

- For **WIDTH (A)**, measure across the window casing from one inside edge to the other in three places, top, middle, and bottom. Record the **smallest** width rounded **down** to the nearest $\frac{1}{8}$ ".
- For **LENGTH (B)**, measure the inside area from the top inside edge down to the top of the sill in three places, left, middle and right. Record the **longest** length rounded **up** to the nearest $\frac{1}{8}$ ".
- The factory will make all the necessary deductions for inside mount.



OUTSIDE MOUNTING (OB)

- For **WIDTH (A)**, measure from one edge of the casing to the other, then add a minimum of 4" (2" each side), for blind overlap. Record the measurement rounded **up** to the nearest $\frac{1}{8}$ ".
- For **LENGTH (B)**, measure from the top of the window sill up to the desired top of the blind. Again, record the measurements rounded **up** to the nearest $\frac{1}{8}$ ".
- Outside mounted blinds are fabricated to order dimensions.



BOTTOM SIDE CUT-OUTS

KENSINGTON SIDE CUT-OUT BLINDS have rectangular areas removed from the blind to avoid obstructions (such as an air-conditioner). Cut-outs may be from the bottom corners of the blind. While a template is not required, when ordering a cut-out blind, a **diagram** of the blind with **all dimensions noted** must be included.




DIAGRAM:

When ordering, include a diagram showing all dimensions:

- A** Overall Width of Blind
- B** Overall Height of Blind
- C** Bottom Width of Blind
- D** Width of Cut-Out (max. 4 inches)
- E** Height of Cut-Out
- F** Length of Shorter Side