

KENSINGTON ALUMINUM HORIZONTAL BLINDS

MEASURING GUIDELINES

Accurate measurements are essential, for both correct pricing and proper fit. Use only a hard-edged ruler or steel tape, never a cloth tape. For inside mounts, width measurements should be rounded down to the nearest 1/8" to prevent blind from binding against the window casing.

INSIDE MOUNTING (IB)

- For **WIDTH (A)**, measure across the window casing from one inside edge to the other in three places, top, middle, and bottom. Record the **smallest** width rounded **down** to the nearest 1/8".
- For **LENGTH (B)**, measure the inside area from the top inside edge down to the top of the sill in three places, left, middle and right. Record the **longest** length rounded **up** to the nearest 1/8".
- The factory will make all the necessary deductions for inside mount.

INSIDE BRACKET MOUNTING REQUIREMENTS:

- Minimum Depth of Mounting Surface Required:..... 1/2"
- Minimum Depth Required for Flush Mount:..... 2 1/8"

OUTSIDE MOUNTING (OB)

- For **WIDTH (A)**, measure from one edge of the casing to the other, then add a minimum of 4" (2" each side), for blind overlap. Record the measurement rounded **up** to the nearest 1/8".
- For **LENGTH (B)**, measure from the top of the window sill up to the desired top of the blind. Again, record the measurements rounded **up** to the nearest 1/8".
- Outside mounted blinds are fabricated to order dimensions.

OUTSIDE BRACKET MOUNTING REQUIREMENTS:

- Minimum Mounting Surface Required:..... 3/4" x 1"
- Minimum Mounting Surface Required when using a Spacer Block or Extension Bracket:..... 1 1/8" x 1 5/16"
- Rail to Mount Surface Clearance:..... 1 1/16"
- Slat End to Mount Surface Clearance 5/16"

